



Body Armor 4x4 by Tolar Mfg.
258 Mariah Circle, Corona CA 92879

Ph: 951-808-0750

Customer service hours:
8am to 4 PM Pacific Time

www.bodyarmor4x4.com

Installation instructions for TJ-4321 & TJ-4322

Tub Rails for Jeep Wrangler TJ (PN TJ-4322) & TJ Wrangler Unlimited (PN TJ-4321)

** Inspect product prior to installation. Call immediately if any discrepancies are found

** The installation of this product requires drilling into the body of the vehicle. Confirm the location of the tub rail before drilling.

Hardware List:

8MM-25MM Hex Head Bolt Qty: 6
8MM Flat washer Qty: 6
8MM Lock Washer Qty: 6
Foam Pad Driver side
Foam Pad passenger side
Driver side Tub Rail
Passenger side Tub Rail

Installation Instructions

- Step 1: Clean the upper portion of the tub to prevent a damage to the paint surface
- Step 2: The location of the Tub Rail will be below the upper lip of the tub running from the rear corner to the door. The angled edge goes closest to the door, the driver side Tub Rail has a notch for the fuel door.
- Step 3: Locate the foam pads. This will be used as the template for drilling the holes. The foam pad has an adhesive side, this side will attach the the back plate for the Tub rail. HOWEVER, do not attach it to the Tub Rail yet. Take the non-adhesive side of the foam pad and tape it to the side of the tub. Once you have determined the exact location of the pad mark and drill your holes. Confirm your location before drilling! Drill 3 8MM (5/16") holes per side.
- Step 4: Peel the protective cover to the foam pad and carefully attach it to the back of the Tub Rail. Carefully line up the Tub Rail with the drilled holes and attach with the 8MM bolts. The Tub Rail attaches from the inside of the vehicle. Be sure to tighten the hardware evenly.

Note: We recommend that you keep the Tub rails clean and touch up and scratches.

Tub rails are not designed to protect passengers from side impact that may occur in a motor vehicle accident